


KZ650-B2, C2 Wiring Diagram (U.S., Canadian Model)



LEFT HANDBAR SWITCH CONNECTIONS

Switch Lockout Switch	Dimmer Switch	Turn Signal Switch	Hazard Switch	Horn Button
Black	Blue	Green	Gray	Black
ON	HI	L	ON	ON
	LO	R		

IGNITION SWITCH CONNECTIONS

Battery 1	Ignition 1	Tail 1	Battery 2	Tail 2	Battery 3	Tail 3
White	Brown	Blue	Red	White	White	White
ON	ON	ON	ON	ON	ON	ON
	OFF					

RIGHT HANDBAR SWITCH CONNECTIONS

Headlight Switch	Starter Button	Engine Stop Switch
Black	Blue	Black
ON	ON	ON
		OFF