


(US, Canadian Model)



LEFT HAND/LEBAR SWITCH CONNECTIONS									
Starter Lockout Switch		Horn Button		Dime Switch		Turn Signal Switch			
Color	Black	Color	Black	Color	Bk/Y	Blue	R/Y	Color	Green
ON		OFF		HI		LO		Left	
ON		LO						Right	

IGNITION SWITCH CONNECTIONS				
Lead	Ignition	Battery	Tail 1	Tail 2
Color	Brown	White	Blue	Red
OFF				
ON	●	●	●	●
PARK		●	●	●

(257-0)

RIGHT HANDLEBAR SWITCH CONNECTIONS					
Starter Button		Engine Stop Switch		Headlight Switch	
Color	Black	R/Y	Color	R/Y	Brown
			Color	Brown	OFF
			OFF		
			RUN		
OFF					
ON		OFF		ON	